DG-600 3m / 3,6m





Scale:1/5 Wingspan: 3000mm / 3600mm (118"/142") Length:1450mm (57") Wing area: max. 64dm ² Wing loading: 58 g / dm ² Airfoil: HQ2-12 Weight: min. 2800g (98oz) Material: Fully moulded 9 servos needed Elevator x 1 Servo, Rudder x 1 Servo, Ailerons x 2 Servos, Flaps x 2 Servos, Airbrakes x 2 Servos, Towrelease x 1 Servo. CG: 35%

Wings



Through hole for Flaps



Glue the main wing locating pins in place (5 mm carbon rods)



Flap servo installation



Servo covers held by tape



Glue the locating pins for te tips (3 mm dia carbon rods)



Ailerons servo installation



Airbrake installation



Servo cover held by tape

Fuselage



Glue anticrush dowel in place



Glue , $\tilde{a} * \hat{A}^{l}c$ [\hat{A} connector in place



Glue Wood reinforcement 20mm x 20mm x 15mm



Install horn in { rudder



Make the holes for the servo connections



Fit and glue servo tray in place



Install pushrod



Glue hinges in place



Ùơʰ]ÁGĐÁĞ)• cæa|Ás@ Áč åå^¦Á,[• dÁsææ&\Á,ãc@ÁÔCE Ùơʰ]ÁrĐÁĞ)• cæa|Ás@ Áč|^çæa[¦Á æa)åÁ ^ &č ¦^Á,ãc@Á[{ ^ Á,ã&^Á?][¢ˆ Áã]|^c اؤ \æ* ^Áæ• Á @ إ}Á§j•ãå^Ás@ ,



Øãjã @k@ ÁÜÔÁ§j•œaa|æaãj}}Á§jÁs@ Cockpitæl^æ



 $|\hat{a}| \hat{a}^{\dagger} \wedge \hat{A}_{0} \hat{a}^{\dagger} \hat{A}_{0} \hat{a}^{\dagger} \hat$



Cockpit



In c@ Á&æ)[]^Á¦æ{ ^Á|`^Áo@ Á^æ¦Á, [[åÁ • [] ^¦



In c@Á¦[} ớ{\ Á@Á&æ;[]^ $\mathsf{Maa}^{\mathsf{A}ab}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{|}\overset{\circ}{}^{\mathsf{A}ac}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{a}}\overset{\circ}{\mathsf{A}}\overset{\circ}{\mathsf{$







Tow release opening





Control throws

O∄^\[}•:Á] 15 mm/å[,} 10 mm Ò|^çæ[¦:`] 8 mm/å[,} 8 mm Ü`åå^\:Áæ&@Áãa^ 35 mm

Thermic

 OEap^{\[}●:: å[, } 2 mm

 Ø[æab]•: å[, } 3 mm

 Speed

 OEap^{\[}●:č] 1 mm

 Ø[æab]•:Á[1 mm

 Landing

 Ø[æab]•:å[, } 24 mm

 O[^cçæab[::å[, } 2 mm

